

PRODUCT NAME:

## PF-M™ Buckles

PART NUMBER:

## **E-BUCKLE**



- A. PlateFrame
- B. Buckles
- C. Velcro Loop Straps



- Insert velcro loop strap with hook side out through horizontal slots of buckle.
- B. The velcro loop strap should be longer through top slot than the bottom slot.
- C. Insert long and short velcro loop strap into the second slot from the top of the Tegris friction adaptor on plateframe.















- Insert long velcro loop strap into top slot of friction adaptor and buckle.
- B. Make sure to pull long velcro loop tight.







- loop strap into
  bottom slot of
  buckle and into third
  slot of the friction
  adaptor. Make sure
  the strap is tight.
- B. Insert the strap into fourth slot.







- Insert strap into fifth slot.
- B. Fold leftover up and the top leftover on top of bottom leftover.Must be tight!



