



END USER INSTRUCTIONS - READ BEFORE USE

PRODUCT NAME:

PECI Cummerbund Adapter

PART NUMBER:
PFMA-PCBAXX

MOUNTING THE PECI TO THE CUMMERBUND ADAPTER



- 1** Place the PECI MOLLE/ PALS adapter next to the PECI. Notice the rectangular window in the middle of the adapter.



- 2** Pass the PECI belt loop through the adapter window.



- 3** Feed the adapter's locking strap through the PECI belt loop.



- 4** Ensure that the locking strap passes underneath the adapter's frame as shown above.



- 5** Feed the locking strap through the adapter's vertical slot as shown above.



- 6** Use a plastic card to break the Velcro hook and loop connection between the locking strap and the PECI belt loop. Feed the locking strap back through the belt loop.



- 7** Remove the plastic card and press the locking strap in place to secure the connection between the Velcro located on the locking strap and the PECI belt loop.



END USER INSTRUCTIONS - READ BEFORE USE

PRODUCT NAME:

PECI Cummerbund Adapter

PART NUMBER:
PFMA-PCBAXX

MOUNTING THE ADAPTER TO THE AUTO-FIT CUMMERBUND™



1 Feed the vertical straps through the horizontal slots located at the top of the adapter.

2 Begin weaving the MOLLE/PALS straps between the MOLLE/PALS field and the adapter. The adapter is designed to mount to two rows of MOLLE/PALS. After passing through the final row of MOLLE/PALS, feed the straps through the horizontal slots located at the bottom of the adapter.



3 Tuck the stiffened tabs back into the MOLLE/PALS row to secure the adapter and Peci in place.