



END USER INSTRUCTIONS - READ BEFORE USE

PRODUCT NAME:

NavBoard® Series

PART NUMBER:

NB-00XX

Standard

with Compass Holds 2 devices



Stubby

with Compass & MOLLE/PALS & Holds 1 small device



Tandem

Holds 1 large device



Mega

with VLite & Compass Holds 2 devices



Stubby

with Compass & Holds 1 medium device



Tandem

with Compass



Non-Standard

Holds 1 large device

Tab

with VLite & Compass Holds 2 devices


Stubby

Holds 2 large devices

Single

Holds 1 large device

REMOVE/ATTACH COMPASS & REPLACE BATTERY



ON/OFF BUTTON

REFERENCE LINE

HOUSING UNIT

* MOUNTING PLATFORMS MAY VARY.

NOTE: Ships with battery installed. One CR-2032 Battery replacement instructions included separately. Battery housing found under the on/off button. To replace battery, remove screw and pull out button from the compass. Pry open back and replace battery.



FLAT HEAD SCREWS

1

To remove compass, remove 4 screws on the back of the Boltaron platform*

2

To attach compass, insert light switch into hole. Reattach screws. Red reference line should be perpendicular to individual when in use.

SINGLE BUTTON OPERATIONS:

CONTROL BRIGHTNESS:

From Off - Press and hold, release at desired brightness. Light will "blink" once at full brightness.

From On - Press and hold to dim, release at desired brightness. Light will "blink" once at lowest brightness.

SAFETY BEACONS:

Press and hold past "blink". You can choose slow beacon, medium beacon, fast flash or SOS.

SIGNAL/MORSE CODE:

Press rapidly (approx. 4 times) until light does not stay on. To exit Signal/Morse Code, press until light turns off.

In the event water gets into the case, simply open the case and allow to dry.