



END USER INSTRUCTIONS - READ BEFORE USE

PRODUCT NAME:

**ELOS™ 5.56**

PART NUMBER:  
**ELOS-556XX**

**PACKAGE INCLUDES:**



A. One ELOS™ 5.56

B./C. GRT™ Belt & Webbing Adapter

**Add-On Options:**

- GRT™ Webbing Adapter
- GRT™ Belt Adapter
- GRT™ Base Plate
- Additional ELOS™ 5.56
- Belt-M System

**NOTE:** Using a flathead screwdriver, remove all hardware from ONE of the ELOS™ 5.56.



**Parallel Assembly**

Attaches to optional GRT™ Base Plate

**IN-LINE ASSEMBLY**



**1**

To attach the ELOS™ in-line, use the holes indicated above.



**2**

Insert the barrel into the bottom ELOS™ and through the hole indicated above. Insert the screw into the barrel and tighten.



**3**

The ELOS™ are now attached for in-line position.

**OFFSET ASSEMBLY**



**1**

To attach the ELOS™ offset from each other, use the holes indicated above.



**2**

Connect the top holes with the screws and using the hole indicated above, attached the second screw.



**3**

The ELOS™ are now attached in the offset position.