PRODUCT NAME:

PTT Wings 02

PART NUMBER:
PTTW-002XX

PACKAGE INCLUDES:

RIGHT WING

LEFT WING

Loop Side Showing

Point-To-Talk (PTT) Wings (Set of 2)

ATTACH THE PTT WINDS TO THE FLIPLITE JACKET

1 Slide the PTT wing between the mounting straps and the back of the FlipLIte Jacket.

2 Slide the second PTT wing between the mounting straps and the back of the FlipLIte Jacket on the other side. Connect the two Velcro strips on the wings.

3 Secure the PTT device and cables with the integrated bungees on the front of the PTT wings.

ATTACHING JACKET TO THE FLIPLITE™

1 Insert FlipLite into the jacket. Pull mounting straps through the top two slots on the back of the jacket.

2 The two straps are ready to be attached to a carrier or the harness.

3 Insert mounting strap tabs back through the bottom slots of the jacket if not using harness.

4 Pull tabs around the top of the FlipLite and lock in place. Repeat for both tabs.

Compatible with: FlipLite Jacket, FlipLIte Harness and CR-M Horizontal MOLLE Panel (shown above).