




END USER INSTRUCTIONS - READ BEFORE USE

PRODUCT NAME:

Interior Load Bearing Wings

PART NUMBER:

PFRA-WF01 (FRONT)
PFRA-WB01 (BACK)



1

Every PF-R™ armor wing upgrade will come with a set of front wing panels (left and right) and a set of back wing panels (left and right). The back wings will have a curve to them. Have the plates already inserted into the PF-R™. This will make install easier.

2

Take the front frame and lay it down so that the comfort pads are facing upwards, remove the comfort pads, and orientate the left and right Tegrifangs so that the Tegrifangs are facing exterior towards the front of the frame and the Velcro loop is facing towards the body. To make sure the left and rights are on the correct side, the Tegrifangs that will connect to the band holding the plate should be facing down.

3

Once you have gauged where the wings will sit; start with the right-side wing and slide the long ends of the wing underneath of the interior wrap while keeping the wider/shorter block exterior of the wrap; as this will Velcro to the wrap to hold in place.




END USER INSTRUCTIONS - READ BEFORE USE

PRODUCT NAME:

Interior Load Bearing Wings

PART NUMBER:

PFRA-WF01 (FRONT)
PFRA-WB01 (BACK)



4

Take the left-side wing and do the same, making sure to connect the long ends of the left wing to the long ends of the right wing by using the Velcro hook on the ends of right wing and the Velcro loop on the left wing.

5

Place the comfort pads back onto the interior of the PF-R™.

6

Now take the back frame and orient the same as the front with the comfort pads facing up, and remove the comfort pads. Much like the front wings, orientate so that the Tegriss is facing exterior and the Velcro loop is facing towards the body; with the Tegriss fangs to attach to the band facing downwards. In addition, the back wings will have a curve to the MOLLE/PALS panel that will orientate out and downwards.



END USER INSTRUCTIONS - READ BEFORE USE

PRODUCT NAME:

Interior Load Bearing Wings

PART NUMBER:

PFRA-WF01 (FRONT)
PFRA-WB01 (BACK)



7

Follow the same instructions of the front mounting wing (step 3); start with the right side sliding the long ends under the wrap and the shorter/wider block exterior.

8

Next slide the left mounting wing, making sure to connect the long ends to each other using the Velcro hook and loop.

9

Place the comfort pads back onto the interior of the PF-R™.

