



PRODUCT NAME:

PF-M™ PlateFrame Modular


PART NUMBER:

PFM-00XX


PLATE CINCHING STRAPS



1 Remove the comfort pad from the Tegriss frame, exposing the plate cinching straps underneath.



2 You'll notice that all of the cinching straps are pulled tight and in order to slide the plate into the PFM you're going to loosen the Velcro tabs attached to the cinching straps.




3 Start with the four cinching straps on the upper portion of the PFM; to loosen simply undo the Velcro tab and slide the cinching straps away from the PFM.



4 Do the same for the larger Velcro panel at the bottom of the PFM.



5 At this point, all cinching straps should be loosened up enough to slide the hard armor plate into the PFM from the bottom. Once the plate is seated, flip the PFM over and do a quick check that the frame is centered up on the hard armor plate.



6 To pull the frame tight to the hard armor plate, start with pulling the four Velcro cinching straps on the upper portion of the PFM back towards the center of the frame. You may need to hand tighten the cinching straps that route around the buckle area for maximum tightening.



7 Secure the hard armor plate by re-applying the larger Velcro panel at the bottom of the PFM to the frame.



8 Lastly, put back on the comfort pad and you're ready to go. The process is the same for both the front and back frames of the PFM.



VIEW USER INSTRUCTIONS OR VISIT
WWW.SSPGEAR.COM/INSTRUCTIONS